


Zubehör Schleifen



Produkt	Bestell-Nr.
① FastFix Polierteller PT-STF-D90 FX-RO90	495625
② FastFix Schleifteller ST-STF D90/7 FX H-HT	495623
③ FastFix Schleifteller ST-STF D90/7 FX W-HT	496804
④ Interface-Pad IP-STF-D90/6	497481
⑤ Schleifschuh SSH-GE-STF-RO90 DX	496802
⑥ Schleifschuh LSS-STF-RO90 V93/6	496803
⑦ Schleifschuh LSS-STF-RO90 V93 E	497483
⑧ Schleifschuh StickFix weich SSH-STF-V93/6-W/2	616630 488715
⑨ Schleifschuh StickFix hart SSH-STF-V93/6-H/2	616628 488716
⑩ SYSTEMAINER T-LOC SYS-STF RO 90 DX	497687
⑪ FastFix Polierteller PT-STF-D125 FX-RO125	492128
⑫ FastFix Schleifteller ST-STF D125/8 FX-H	492127
⑬ FastFix Schleifteller ST-STF D125/8 FX-W-HT	616713 492125
⑭ FastFix Schleifteller ST-STF D125/8 FX-SW	492126

Produkt	Bestell-Nr.
⑮ Interface-Pad IP-STF-D120/90/8	492271
⑯ FastFix Polierteller PT-STF-D150 FX	616721 496151
⑰ FastFix Schleifteller ST-STF D150/17MJ-FX-H	616239 496149
⑱ FastFix Schleifteller ST-STF D150/17MJ-FX-W-HT	616241 496147
⑲ FastFix Schleifteller ST-STF D150/17MJ-FX-SW	616243 496144
⑳ Interface-Pad IP-STF D 150/17 MJ (Höhe: 15 mm)	496647
Interface-Pad IP-STF D 150/17 MJ-S2x (Höhe: 5 mm)	499257
㉑ Schleifteller ST-STF ES125/90/8-M4 W-HT	616715 492280
㉒ Schleifteller ST-STF ES125/90/8-M4 SW	492282
㉓ Polierteller PT-STF-D150 M8	496152
㉔ Schleifteller ST-STF D150/17MJ-M8-H	616709 496150
㉕ Schleifteller ST-STF D150/17MJ-M8-W	616719 496160
㉖ Schleifteller ST-STF D150/17MJ-M8-W-HT	616717 496148
㉗ Schleifteller ST-STF D150/17MJ-M8-SW	616711 496145